

BEVERAGE FOUNTAIN INSTRUCTIONS

**** DO NOT USE ANY THICK OR SLUSHEE BEVERAGES SUCH AS A SHERBERT PUNCH****

****DO NOT USE ANY BEVERAGES WITH PULP. IF USING PINEAPPLE JUICE, STRAIN BEFORE USING****

****FOUNTAIN WILL NOT KEEP YOUR BEVERAGE COLD. YOU MUST REFRIGERATE YOUR PUNCH BEFORE PUTTING IT IN THE FOUNTAIN****

TO OPERATE:

1. SET MACHINE ON LEVEL SURFACE.
2. FILL BOWL WITH BEVERAGE. MAKE SURE TO ALWAYS COVER HOLES ON BOTTOM OF TOWER. THIS IS WHERE THE MOTOR PULLS FROM – IF THERE IS NOT ENOUGH LIQUID THE MOTOR WILL BURN UP.
3. (DOME FOUNTAIN ONLY) PLACE DOME ON TOP OF FOUNTAIN. MAKE SURE DOME IS FIT SNUGGLY ON TOP OF THE BOWL.
4. FLIP SMALL SILVER SWITCH TO ON POSITION. FOUNTAIN WILL BEGIN TO FLOW.
5. ****TO REFILL TIERED FOUNTAIN - POUR MORE BEVERAGE INTO BOWL (CAN KEEP FOUNTAIN ON WHILE REFILLING).**
****TO REFILL DOME FOUNTAIN – TURN FOUNTAIN OFF AND REMOVE DOME. POUR MORE BEVERAGE INTO BOWL. REPLACE DOME. TURN FOUNTAIN ON TO RESUME FLOW.**
6. AFTER USE, TURN OFF FOUNTAIN AND POUR OUT ANY EXTRA BEVERAGE LEFT IN BASIN.
7. FILL WITH CLEAN WATER AND TURN FOUNTAIN ON FOR A FEW MINUTES TO RINSE. POUR OUT WATER AND DRY BOWL.

HINTS

YOU MAY FILL ICE CUBE TRAYS WITH YOUR PUNCH AND FREEZE THEM. YOU CAN CRACK THE CUBES INTO THE BOWL TO HELP KEEP IT COLD WITHOUT DILUTING YOUR PUNCH.