

## English

### 3) PERSONAL SAFETY

- a) Stay alert, watch what you are doing and use common sense when operating a power tool. Do not use a power tool while you are tired or under the influence of drugs, alcohol or medication. A moment of inattention while operating power tools may result in serious personal injury.
  - b) Use personal protective equipment. Always wear eye protection. Protective equipment such as dust mask, non-skid safety shoes, hard hat, or hearing protection used for appropriate conditions will reduce personal injuries.
  - c) Prevent unintentional starting. Ensure the switch is in the off position before connecting to power source and/or battery pack, picking up or carrying the tool. Carrying power tools with your fingers on the starting power switch is a common accident cause.
  - d) Remove any adjusting key or wrench before turning the part of the power tool may result in personal injury.
  - e) Do not overreach. Keep proper footing and balance at all times. This enables better control of the power tool in unexpected situations.
  - f) Dress properly. Do not wear loose clothing or jewelry. Keep your hair, clothing and gloves away from moving parts. Loose clothes, jewelry or long hair can be caught in moving parts.
  - g) If devices are provided for the connection of dust extraction and collection facilities, ensure these are connected and properly used. Use of dust collection can reduce dust-related hazards.
- 4) POWER TOOL USE AND CARE
- a) Do not force the power tool. Use the correct power tool for your application. The correct power tool will do the job better and safer at the rate for which it was designed.

b) Do not use the power tool if the switch does not turn it on and off. Any power tool that cannot be controlled with the switch is dangerous and must be repaired.

- c) Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools. Such preventive safety measures reduce the risk of starting the power tool accidentally.
  - d) Store idle power tools out of the reach of children and do not allow persons unfamiliar with the tool. Power tools are instructions operate the tools of untrained users.
  - e) Maintain power tools. Check for misalignment or binding of moving parts, breakage of parts and any other condition that may affect the power tool's operation. If damaged, have the power tool repaired before use. Many accidents are caused by poorly maintained power tools.
  - f) Keep cutting tools sharp and clean. Properly maintained cutting tools with sharp cutting edges are less likely to bind and are easier to control.
  - g) Use the power tool, accessories and tool bits, etc. in accordance with these instructions, taking into account the working conditions and the work to be performed. Use of the power tool for operators different from those intended could result in a hazardous situation.
- 5) BATTERY TOOL USE AND CARE
- a) Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
  - b) Use power tools only with specifically designated battery packs. Use of any other battery packs may create a risk of injury and fire.

If you have questions or comments, contact us.

Pour toute question ou tout commentaire, nous contacter.

Si tiene dudas o comentarios, contáctenos.

1-800-4-DEWALT • [www.dewalt.com](http://www.dewalt.com)

## INSTRUCTION MANUAL GUIDE D'UTILISATION MANUAL DE INSTRUCCIONES

INSTRUCTIVO DE OPERACIÓN, CENTROS DE SERVICIO Y PÓLIZA DE GARANTÍA. ADVERTENCIA: LEA ESTE INSTRUCTIVO ANTES DE USAR EL PRODUCTO.

# DEWALT

DCCS374

20V Max\* XR Li-Ion Brushless Band Saw

Scie à ruban sans balai XR Li-Ion 20 V Max\*

Sierra de banda sin escobillas de 20V Max\* XR de iones de litio

### Definitions: Safety Guidelines

The definitions below describe the level of severity for each signal word. Please read the manual and pay attention to these symbols.

**DANGER:** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

**WARNING:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**NOTICE:** Indicates a practice not related to personal injury which, if not avoided, may result in property damage.

IF YOU HAVE ANY QUESTIONS OR COMMENTS ABOUT THIS OR ANY DEWALT TOOL, CALL US TOLL FREE AT: 1-800-4-DEWALT (1-800-433-9258).

**WARNING:** To reduce the risk of injury, read the instruction manual.

### General Power Tool Safety Warnings

**WARNING:** Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.

**SAVE ALL WARNINGS AND INSTRUCTIONS FOR FUTURE REFERENCE**

The term "power tool" in the warnings refers to your mains-operated (corded) power tool or battery-operated (cordless) power tool.

### 1) WORK AREA SAFETY

- a) Keep work area clean and well lit. Cluttered or dark areas invite accidents.
  - b) Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite the dust or fumes.
  - c) Keep children and bystanders away while operating a power tool. Distractions can cause you to lose control.
- 2) ELECTRICAL SAFETY
- a) Power tool plugs must match the outlet. Never modify the plug in any way. Do not use any adapter plugs with earthed (grounded) power tools. Unmodified plugs and matching outlets will reduce risk of electric shock.
  - b) Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges and refrigerators. There is an increased risk of electric shock if your body is earthed or grounded.
  - c) Do not expose power tools to rain or wet conditions. Water entering a power tool will increase the risk of electric shock.
  - d) Do not abuse the cord. Never use the cord for carrying, pulling or unplugging the power tool. Keep cord away from heat, oil, sharp edges or moving parts. Damaged or entangled cords increase the risk of electric shock.
  - e) When operating a power tool outdoors, use an extension cord suitable for outdoor use. Use of a cord suitable for outdoor use reduces the risk of electric shock.
  - f) If operating a power tool in a damp location is unavoidable, use a ground fault circuit interrupter (GFCI) protected supply. Use of a GFCI reduces the risk of electric shock.

## English



such as those dust masks that are specially designed to filter out microscopic particles.

- Avoid prolonged contact with dust from power sanding, sawing, grinding, drilling, and other construction activities. Wear protective clothing and wash exposed areas with soap and water. ...

- Do not operate the charger with a damaged cord or plug.
• Do not place any object on top of the charger or place the charger on a soft surface that might block the ventilation slots and result in excessive internal heat. ...

IPM: impacts per minute RPM: revolutions per minute SPM: strokes per minute

Important Safety Instructions for All Battery Packs

When ordering replacement battery packs, be sure to include the catalog number and voltage. Consult the chart at the end of this manual for compatibility of chargers and battery packs.

READ ALL INSTRUCTIONS

- Do not operate the charger with a damaged cord or plug.
• Do not use an extension cord unless it is absolutely necessary. Use of improper extension cord could result in risk of electric shock or electrocution. ...

- Always keep your hands out of the line of the band saw blade.
• Always wait until the motor has reached full speed before starting a cut.
• Always keep handles dry, clean, and free of oil and grease. ...

Additional Safety Rules - Portable Band Saws

- Hold power tool by insulated gripping surfaces when performing an operation where the cutting accessory may contact hidden wiring.
• Always make sure the portable band saw is clean before using.
• Always use proper personal hearing protection. ...

WARNING: Shock hazard! Do not allow any liquid to get inside the charger. Electric shock may result.

- Do not use an extension cord unless it is absolutely necessary. Use of improper extension cord could result in risk of electric shock or electrocution.
• When operating a charger outdoors, always provide a dry location and use an extension cord suitable for outdoor use. ...

Table with columns: Amperage Rating, Voltage, Minimum Gauge for Cord Sets, Total Length of Cord in Feet (meters), and AWG. It lists specifications for 120V and 240V chargers.

- Do not place any object on top of the charger or place the charger on a soft surface that might block the ventilation slots and result in excessive internal heat.
• Do not operate the charger with a damaged cord or plug. ...

- Contents of opened battery cells may cause respiratory irritation. Provide fresh air if symptoms persist, seek medical attention.
• WARNING: Burn hazard! Battery liquid may be flammable if exposed to spark or flame.
• The RBRC's Seal ...



The RBRC's (Rechargeable Battery Recycling Corporation) Seal on the nickel cadmium, nickel metal hydride or lithium-ion batteries (or battery packs) indicates that the costs to recycle these batteries (or battery packs) at the end of their useful life have already been paid for by RBRC. ...



**HOT/COLD DELAY**

DCB101, DCB102, DCB103

These chargers have a hot/cold delay feature. When the charger detects a battery that is too hot or too cold, it automatically starts a delay, suspending charging. The red light flashes long, then short while in the hot/cold delay mode.

Once the battery has reached an optimum temperature, the charger will automatically resume the charging procedure. This feature ensures maximum battery life.

DCB107, DCB112, DCB113, DCB115

These chargers have a hot/cold delay feature. When the charger detects a battery that is too hot or too cold, it automatically starts a delay, suspending charging. The red light will continue to blink, but a yellow indicator light will be illuminated during this suspension.

Once the battery has reached an optimum temperature, the yellow light will turn off and the charger will automatically resume the charging procedure. This feature ensures maximum battery life.

**LEAVING THE BATTERY PACK IN THE CHARGER**

The charger and battery pack can be left connected with the charge indicator showing Pack-Charged.

**WEAK BATTERY PACKS:** Weak batteries will continue to function, but should not be expected to perform as much work.

**FAULTY BATTERY PACKS**

DCB101, DCB102, DCB103

These chargers will not charge a faulty battery pack. The charger will indicate faulty battery pack by refusing to light or by displaying problem **NOTE:** This could also mean a problem with a charger.

DCB107, DCB112, DCB113, DCB115

These chargers will not charge a faulty battery pack. The charger will indicate faulty battery pack by refusing to light.

**NOTE:** This could also mean a problem with a charger.

**Wall Mounting**

DCB107, DCB112, DCB113, DCB115

These chargers are designed to be wall mountable or to sit upright on a table or work surface. If wall mounting, locate the charger within reach of an electrical outlet. Mount the charger securely using drywall screws at least 1" (25.4 mm) long, screwed into solid wall or ceiling. Do not drill leading approximately 7/32" (9.5 mm) of the screw exposed.

**Important Charging Notes**

1. Longest life and best performance can be obtained if the battery pack is charged when the air temperature is between 65 °F and 75 °F (18°–24 °C). **DO NOT** charge the battery pack in an air temperature below +40 °F (+4.5 °C) or above +104 °F (+40 °C). This is important and will prevent serious damage to the battery pack.

2. The charger and battery pack may become warm to the touch while charging. This is a normal condition, and does not indicate a problem. To facilitate the cooling of the battery pack after use, avoid placing the charger or battery pack in a warm environment such as in a metal shed or an uninsulated trailer.

3. A cold battery pack will charge at about half the rate of a warm battery pack. The battery pack will charge at that slower rate throughout the entire charging cycle and will not return to maximum charge rate even if the battery pack warms.

4. If the battery pack does not charge properly, a. Check operation of receptacle by plugging in a lamp or other appliance.

• Do not operate the charger if it has received a sharp blow, been dropped or otherwise damaged in any way. Take it to an authorized service center.

• Do not disassemble the charger. Take it to an authorized service center for repair.

• Disassembly of the charger from the outlet before attempting any charging. This will reduce the risk of electric shock.

• **NEVER** attempt to connect 2 chargers together.

• The charger is designed to operate on standard 120V household electrical power. Do not attempt to use it on any other voltage. This does not apply to the vehicular charger.

**Chargers**

Your tool uses a DEWALT charger. Be sure to read all safety instructions before using your charger. Consult the chart at the end of this manual for the compatibility of chargers and battery packs.

**Charging Procedure**

1. Plug the charger into an appropriate outlet before inserting the battery pack.
2. Insert the battery pack (A) into the charger, as shown in Figure 1. The red light (B) will flash when the tool (charging) has started.
3. The completion of charge will be indicated by the red light remaining ON continuously. The pack is fully charged and may be used at this time or left in the charger.




FIG. 1

**Indicator Light Operation**

DCB101, DCB102, DCB103

PACK CHARGING — — — — —

PACK CHARGED — — — — —

HOT/COLD DELAY — — — — —

PROBLEM PACK OR CHARGER — — — — —

DCB107, DCB112, DCB113, DCB115

PACK CHARGING — — — — —



PACK CHARGED — — — — —

HOT/COLD DELAY — — — — —

**Charge Indicators**

This charger is designed to detect certain problems that can arise. Problems are indicated by the red light flashing at a fast rate. If this occurs, re-insert the battery pack into the charger. If the problem persists, try a different battery pack to determine if the charger is working properly. If the new pack charges correctly, then the original pack is defective and should be returned to a service center or other collection site for recycling. If the new battery pack clicks the same trouble indication as the original, have the charger and the battery pack tested at an authorized service center.

FIG. 2




To unlock the trigger switch, press the lock-off button as shown in Figure 3. Pull the trigger switch to turn the motor ON. Releasing the trigger switch turns the motor OFF.

**WARNING:** This tool has no provision to lock the switch in the ON position, and should never be locked ON by any other means.

The variable speed trigger switch will give you added versatility. The further the trigger is depressed the higher the speed of the saw.

**CAUTION:** Use of very slow speed is recommended only for beginning a cut. Prolonged use at very slow speed may damage your saw.



**LED Worklight (Fig. 2)**

**CAUTION:** Do not stare into worklight. Serious eye injury could result.

**SAVE THESE INSTRUCTIONS FOR FUTURE USE**

**COMPONENTS (Fig. 2, 4)**

**WARNING:** Never modify the power tool or any part of it. Damage or personal injury could result.

- A. Multi-position ball handle
- B. Lock-off button
- C. Trigger switch
- D. Main handle
- E. Work stop (Fig. 2, 4)
- F. Guide rollers (Fig. 4)
- G. Adjustment locking nut
- H. Adjustment screw
- I. Blade tension lever
- J. Hex wrench
- K. Speed wheel
- L. Worklight
- M. Hex hook (Fig. 4)
- N. Pulley (Fig. 4)
- O. Blade guard (Fig. 4)
- P. Rubber tires (Fig. 4)
- Q. Blade (Fig. 2, 4)

**INTENDED USE**

This heavy-duty band saw is designed for professional metal cutting applications.

**DO NOT** use under wet conditions or in presence of flammable liquids or gases.

The band saw is a professional power tool. **DO NOT** let children come into contact with the tool. Supervision is required when inexperienced operators use this tool.

**Variable Speed Trigger Switch (Fig. 2)**

Your saw is equipped with a lock-off button (B).

To lock the trigger switch (C), press the lock-off button as shown in Figure 3. Always lock the trigger switch (C) when carrying or storing the tool to eliminate unintentional starting.



bound to the material, possibly resulting in overload and burn-out of the motor.

BLADE DESCRIPTION			
Type of hand saw blade	BH-Metal	BH	BM
Number of teeth	24	18	14
Workpiece thickness	1.8" (45.7 mm)	1.4" (35.4 mm)	1.1" (27.9 mm)
	1.6" (40.6 mm)	1.2" (30.5 mm)	0.9" (22.9 mm)

**Blade Speed**

Your DCS374 portable band saw is equipped with variable speed for greater versatility. Turn the speed wheel (K) to select the desired speed (Fig. 2). Speed 1 is the slowest speed; Speed 5 is the fastest. Use speed settings 1-5.

When cutting copper, brass, bronze, aluminum, cast iron, angle iron, and mild steel, use a higher speed. When cutting plastic pipe, tougher steels, chrome steel, tungsten steel stainless steel, and other problem materials, use low speed.

**Blade Tracking (Fig. 2)**

**WARNING:** To reduce the risk of serious personal injury, turn tool off and remove the battery pack before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.

Your band saw is equipped with an adjustable blade tracking mechanism which assures proper blade tracking at all times. The back edge of a properly aligned blade will run lightly against one or both of the back-up rollers in the blade guides. (The pressure between the edge of the blade and the roller will be very slight and will not damage either the blade or the roller.)

**TO ADJUST THE BLADE TRACKING**

1. Use a 1/2" (13 mm) wrench to loosen the adjustment locking nut (G), shown in Figure 2 by turning it one or two turns counterclockwise.
2. Use a screwdriver to turn the adjustment screw (H) 1/4 turn. Turning the screw clockwise will move the blade up toward the blade guide rollers; turning the screw counterclockwise will move the blade down away from the blade guide rollers.
3. Adjust the blade tracking until the adjustment locking nut. (It will be necessary to insert the battery pack and turn the saw to observe the tracking.)
4. Observe blade tracking between turns and repeat Steps 1-4 as necessary to achieve proper blade tracking.

**WARNING:** Make sure the battery is removed if further tracking adjustment is needed.

**ASSEMBLY AND ADJUSTMENTS**

**WARNING:** To reduce the risk of serious personal injury, turn tool off and remove the battery pack before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.


**Installing and Removing the Battery Pack (Fig. 1, 2, 5)**

**NOTE:** For best results, make sure your battery pack is fully charged. To install the battery pack (F) into the tool handle, first position the bail handle fully forward, then align the battery pack with the rails inside the tool's handle and slide it into the handle until the battery pack is firmly seated in the tool and ensure that it does not disengage. To remove the battery pack (F) from the tool, press the release button (S) and firmly pull the battery pack out of the tool handle. Insert it into the charger as described in the charger section of this manual.

4. Inspect the guide rollers (N) and remove any large chips which may be lodged in them that might cause an undesirable rotation of the guide rollers.
5. Rubber tires (P) are mounted on the pulleys (N). The rubber tires should be inspected for looseness or damage when changing the blade. Wipe any chips from the rubber tires on the pulleys. This will extend their life and keep the blade from slipping. If any looseness or damage occurs, the tool should be brought to an authorized DEWALT service center for repair or replacement as soon as possible. Continued use of the tool with loose or damaged rubber tires will cause unstable level of the band saw blade.

**TO INSTALL BLADE (Fig. 2, 4, 7-9)**

1. Position the blade so that the teeth are on the bottom and angled toward the work stop, as shown in Figure 7.



2. Slip the blade into the guide rollers, as shown in Figure 8.
3. Holding the blade in the guide rollers, slide it against the pulleys (N) (Fig. 4) until the blade (E) is seated into the guide rollers and make sure that the blade is fully seated into the guide rollers.
4. Rotate the blade tension lever (I) counterclockwise until it stops and then gently turn the saw over so that the pulleys rest on your work bench or table. Make sure the teeth face away from the band saw (Fig. 7).
5. Turn the saw on and off a few times to ensure that the blade is seated properly.

FIG. 8





FIG. 9




**Multi-Position Bail Handle (Fig. 2)**

A bail handle (A) is provided for carrying the tool and for use as an additional handle. Assemble the bail handle in one of the multi-positions (forward, 22.5°, 45°, or straight up) shown in Figure 2. When adjusting the bail handle from one position to the other, loosen the bail handle knob and move the handle to one of the three positions and tighten knob.

**WARNING:** Make sure the bail handle knob is tightened and the bail handle is secure before using the saw.

There is a worklight (L) located above the blade. The worklight is activated when the trigger switch is held for 20 seconds after the trigger switch is released. If the trigger switch remains depressed, the worklight will remain on.

FIG. 4



**FUEL GAUGE BATTERY PACKS (Fig. 6)**

Some DEWALT battery packs include a fuel gauge which consists of three green LED lights that indicate the level of charge remaining in the battery pack. The fuel gauge is an indication of approximate levels of charge remaining in the battery pack according to the following indicators:

- 75-100% Charged
- 51-74% Charged
- < 50% Charged
- Pack needs to be charged

To activate the fuel gauge, press and hold the fuel gauge button (T). A combination of the three green LED lights will illuminate designating the level of charge left. When the level of charge in the battery is below the usable limit, the fuel gauge will not illuminate and the battery will need to be recharged.

FIG. 6



**NOTE:** The fuel gauge is only an indication of the charge left on the battery pack. It does not indicate tool functionality and is subject to variation based on product components, temperature and end-user application.

For more information regarding fuel gauge battery packs, please contact call 1-800-4-DEWALT (1-800-433-9228) or visit our website [www.dewalt.com](http://www.dewalt.com).

**Removing and Installing Blades**

**WARNING:** To reduce the risk of serious personal injury, turn tool off and remove the battery pack before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.

**CAUTION:** Cut Hazard. Blade tension lever is under spring pressure. Maintain control of lever when releasing blade tension.

**TO REMOVE BLADE (Fig. 2, 4)**

1. Rotate the blade tension lever (I) clockwise until it stops to release tension in blade (refer to Figure 2).
2. Remove the blade (E) and place it on a workbench or table with the handle to the right.
3. Before removing the blade at the upper portion of the blade guard (O) and continue around the pulleys (N). When removing the blade, tension may be released and the blade may spring free. SAW BLADES ARE SHARP. USE CARE IN HANDLING THEM.

### Work Stop Adjustment

To support large workpieces, the work stop should be lowered following these steps:

1. Loosen the two screws (U), shown in Figure 9, with the hex wrench (A) provided.
2. Move the work stop (E) to the desired position.
3. Securely tighten screws (U).

### Installing the Brush and Brush Cap (Fig. 10)

**WARNING:** To reduce the risk of serious personal injury, turn tool off and remove the battery pack before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.

**NOTE:** The brush/brush cap assembly is available at extra cost from your local dealer or authorized service center.

1. Turn the saw over and place it on a workbench or table with the handle to the right.
2. First, slide the brush (V) into the slot, as seen in Figure 10, then place the brush cap (W) over top and screw securely into place.




FIG. 10

**OPERATION**  
**WARNING:** To reduce the risk of serious personal injury, turn tool off and remove the battery pack before making any adjustments or removing/installing attachments or accessories. An accidental start-up can cause injury.  
There are certain applications for which this tool was designed.

This hand saw is designed to cut various types of material up to 4-3/4" (120.7 mm) diameter or 5" (127 mm) x 4-3/4" (120.7 mm) rectangular shape at 90°.

**WARNING:** Thoroughly remove any oil or grease from the workpiece before securing in a vise or other clamping device. If the workpiece is not secure, it may come loose during the cutting and/or cause breakage, which may result in serious personal injury.

### Cutting

Refer to Figure 12 for recommended cutting positions for various materials.

**NOTE:** Select and use a hand saw blade that is most appropriate for the material being cut. See Blade Description.

This portable hand saw may be hung using the hanging hook (A, Fig. 4). Hang tool on a pipe vise or other suitable, stable structure.

**WARNING:** To reduce the risk of injury, the hanging hook for your own support or to help you maintain a steady tool balance.

**WARNING:** Never attempt to use this tool by resting it upside down on a work surface and digging the material to the tool. Always securely clamp the workpiece and hold the tool to the workpiece, securely holding the tool with two hands as shown in Figure 11.

1. Mount the material to be cut solidly in a vise or other clamping device.
2. Bring the work stop (E) into contact with the workpiece while keeping the blade off of the workpiece. Turn the saw on.
3. When saw reaches desired rotation speed, slowly and gently tilt the main body of the tool to bring the hand saw blade into contact with the workpiece. Apply additional pressure in excess of the weight of the main body of the tool. Carefully avoid bringing the hand saw blade suddenly and heavily into contact with the upper surface of the workpiece. This will cause serious damage to the