

KNEE KICKER

1. The knee kicker is to be used on light carpet stretching only.
2. Five adjustment settings are available to suit individual posture and working conditions. It extends from 17 ½ " to 21 ½". To adjust, turn kicker upside down. Grasp bumper body with one hand and hold shank of kicker with the other. Press trigger and push or pull bumper body until kicker is at desired length. Release trigger and pull bumper body out about 1/8" until a sharp click is heard. Push bumper body forward to complete action. When trigger is flush with bottom plate, the kicker is positively locked in position.
3. The knee kicker is equipped with both steel teeth and nap-grip inserts. The inserts are for use when installing lightweight carpet. Make certain that the steel teeth are retracted when using the inserts. Steel teeth may be extended and retracted. Simply turn the calibrated dial to adjust for carpet nap depth and backing penetration. Each click-stop of the dial moves the teeth 1/32" vertically and holds them securely at each of 16 different positions.
4. The inserts are so positioned that they pull the carpet directly over the pins of carpet gripper and automatically hook the carpet at the peak of the kick. The kicker is designed to be held comfortably at the balance point of the shank. Place the kicker head far enough from the wall so that at the peak of the kick, the front of the head comes close to the wall but does not touch it. When kicking where no wall exists, avoid letting the kicker teeth hit metal moldings.
5. The bumper pad is seamless and foam filled.