

# DRYWALL SANDER

## SAFETY RULES

1. **USE A RESPIRATOR** : Ventilate work area and /or use a dust collector. Continued and prolonged exposure to high concentrations of airborne dust affect the respiratory system function.
2. **MAINTAIN FIRM FOOTING AND BALANCE.** Use appropriate scaffolding. Do not overreach.
3. **SANDING OF LEAD BASED PAINT NOT RECOMMENDED.** Lead based paint should only be removed by a professional.
4. **SOME WOOD CONTAINS PRESERVATIVES WHICH CAN BE TOXIC.** Take extra care to prevent inhalation and skin contact when working with these materials. Request and follow any safety information available from your material supplier.
5. **WARNING:** This tool was designed for certain applications. **DO NOT** modify and / or use it for any application other than for which it was designed. If you have any questions relative to its application

## OPERATING INSTRUCTION

Drywall sander should be held with both hands on the main tube. The hands may be positioned anywhere along the main tube to provide the best combination of reach and leverage for the particular application.

### TO START AND STOP DRYWALL SANDER

Be certain that the power circuit voltage is the same as that shown on the spec plate of the tool, and that the switch is OFF. Connect

the tool to the power circuit. The drywall sander is equipped with a “rocker” type switch. The top end of the switch button is labeled OFF and the bottom end of the switch is labeled O. To start the sander, press the button ON end of the switch. To stop the sander press the top OFF switch.

### SPEED CONTROL

The speed control knob is numbered “1” thru “5”. The setting “1” is slowest speed (approximately 1000 rpm) and “5” is the fastest speed ( approximately 2000 rpm). Use the higher speed setting for fast stock removal. Use the lower speed setting to reduce removal rate for a more precise control.

## ABRASIVE PAD REPLACEMENT

1. Grasp the abrasive pad and the sander housing to prevent rotation.
2. Rotate the pad retaining nut counterclockwise and remove.
3. Lift off the large metal washer and the abrasive pad. Position the new abrasive pad to the back up disc, and center the hole of the disc on the hub of the back up disc.
4. Position the large metal washer and the retaining nut to the sander.
5. Rotate the retaining nut clockwise to hand tighten while holding pad.